


# SI, S1A, S2, S2A Wiring Diagram ('72~'73)

## Ignition Switch Connections

**Note**  
 1. Front brake lamp switch US models only.  
 2. Front parking light and C.L. position of ignition switch European models only.



|             | Batt | Coil | H.L. | Tail | C.L. |
|-------------|------|------|------|------|------|
| OFF         |      |      |      |      | *    |
| ON          | ●    | ●    | ●    | ●    |      |
| CITY LIGHTS | ●    | ●    |      | ●    | ●    |
| PARK        | ●    |      |      | ●    | *    |

\* Key removable