


# SIB, SIC, S3, S3A Wiring Diagram ('74~'75)

(US model)



Dimmer Switch  
Turn Signal Switch  
Horn Button

Ignition Switch Connections

| Lead  | Ig.  | Gr   | H.L. | Tail | Battery | C.H.  |
|-------|------|------|------|------|---------|-------|
| Color | Bk/W | Bk/Y | Blue | R/W  | White   | Brown |
| OFF   | •    | •    |      |      | •       | •     |
| ON    | •    |      | •    |      | •       | •     |
| PARK  | •    | •    |      | •    | •       | •     |